

Jett with IMap software

A few things you should know, if you won't read the manual

Jett hardware

- pressing the on/off button briefly puts the unit in SUSPEND mode (i.e it's not off, but the battery will keep your current program sleeping for up to 30 days)
- press the on/off button for more than 8 seconds to switch the unit off completely, same as taking battery out. All programs and data in non-permanent memory are lost.



Software installation and memory :

- storage is only permanent in the `\systemCF` folder and folders in additional CF cards.
- all other folders are **not** permanent and so:

Set your data file locations (or at least your backup file locations) to the `\systemCF` folder
In IMap, go to the File/Settings menu and then select the Settings tab sheet

To make starting up easier after the Jett has been switched OFF completely or the battery has been taken out Total Survey Systems will do the following before delivery:

1. install the software in the `\systemCF` folder and get an activation key
2. create a shortcut `Imap.lnk`
3. place a file called `Filecopy.txt` in the `\systemCF` folder which will copy the IMap shortcut to the desktop during start-up. This file `filecopy.txt` contains the command:
`copy \SystemCF\IMap\imap.lnk \Windows\Desktop\IMap.lnk`

Storage

For long term storage, make sure all data has been transferred, charge the battery and then remove the battery from the controller. Discharge and re-charge at least once per year.

If the above rules for software installation have been followed, getting the IMap software on the controller up and running after long storage is as simple as inserting the battery, switching on and tapping the IMap icon.