



DocNr: 00047

Last updated: 02/05/99

Product Group: SDR Mapping & Design

Feature Categories: Config.

Title: **INSTALL REBUILD**

INSTALL REBUILD and its effect on SDRmap

This command rebuilds the system data files and will not harm any data that has already been produced. It will set all the CONFIGURATION settings back to default settings.

Should you come up with an error that REBUILD DATABASE cannot clear up, this command may help. Type INSTALL REBUILD at the \SDRSYS or \MAPSYS directory to run. Note that all your settings has to be checked if an install rebuild took place.

THE INFORMATION IN THIS KNOWLEDGE BASE IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND.

©2003 Sokkia B.V. All rights reserved. **Legal Notices**

Created by Robert Schmitz/SUPPORT/SOKKIA/EU at 02/03/99 04:46:31 PM

Last saved by Robert Schmitz/SUPPORT/SOKKIA/EU at 02/05/99 09:51:40 AM

Submitted for approval by Robert Schmitz/SUPPORT/SOKKIA/EU at 04-02-99 01:52:29 PM to Tiny Nuiten/SUPPORT/SOKKIA/EU, Robert Schmitz/SUPPORT/SOKKIA/EU

Approved by Tiny Nuiten/SUPPORT/SOKKIA/EU at 02/04/99 02:52:19 PM